






1




2





4




Always guy the product to prevent it from being damaged by the wind

i




Wind can damage the product when it inflates/deflates or is switched off







1




2



Always ballast  
or anchor the product  
to prevent it from moving



3



The blower must  
never be obstructed

